

TexWipe



## Tuch VersaWipe #STX624

pure<sup>11</sup>-Nr.: 1130159, Marke: TexWipe

### Eigenschaften

- Steril
- Marke: TexWipe
- Flächengewicht in g/m<sup>2</sup>: 60 g/m<sup>2</sup>
- Struktur: Vliesstoff
- Material: Polyester/Zellulose
- Lieferform in Verpackung: gelegt
- Verpackungsform: Beutel
- Anzahl in kleinster Unterverpackung: 50
- Kantenverarbeitung: Kalt geschnitten
- Gebrauch: Einweg
- Polyester/PES: 45 %
- Sterilisation validiert
- Vorgewaschen
- Zellulose: 55 %
- Flächengewicht in g/m<sup>2</sup>: 60 g/m<sup>2</sup>

### Empfohlene Reinraumklassen

ISO 5|6|7|8|9

GMP C|D



## Material

- Polyester/Zellulose

## Verpackung

- 50STK

## Produktvarianten

---

**pure<sup>11</sup>-Nr.: 1130159, Tuch VersaWipe #STX624**

Steril, Größe: 10 cm x 10 cm (4 x 4"); Farbe: Weiß / VE: 50STK

---

TECHNICAL DATA SHEET

**Performance Characteristics**

Property	Typical Value	Test Method*
<b>Particles and Fibers</b> LPC: ≥0.5 µm Fibers: >100 µm	63 x 10 <sup>6</sup> particles/m <sup>2</sup> 50,000 fibers/m <sup>2</sup>	1, TM22 2, TM22
<b>Nonvolatile Residue</b> IPA extractant DIW extractant	0.01 g/m <sup>2</sup> 0.03 g/m <sup>2</sup>	1, TM1 1, TM1
<b>Ions</b> Sodium Potassium Chloride	31 ppm 3.5 ppm 16 ppm	1, TM18 1, TM18 1, TM18

**Physical Characteristics**

Property	Typical Value	Test Method*
<b>Absorbency</b> Sorbptive capacity Sorbptive rate	280 mL/m <sup>2</sup> <1 second	1, TM20 1, TM20
<b>Basis Weight</b>	60 g/m <sup>2</sup>	1, TM20

**\*Test Methods**

1 – “Evaluating Wiping Materials Used in Cleanroom and Other Controlled Environments,” IEST-RP-CC004.3, Institute for Environmental Sciences and Technology, Rolling Meadows, IL, 2004; [www.iest.org](http://www.iest.org).

2 – E2090-12, “Standard Test Method for Size-Differentiated Counting of Particles and Fibers Released from Cleanroom Wipers Using Optical and Scanning Electron Microscopy,” ASTM International, West Conshohocken, PA, 2012; [www.astm.org](http://www.astm.org).

TM – Refers to Texwipe Test Method – available upon request. Contact Texwipe Customer Service at [www.texwipe.com](http://www.texwipe.com) or [info@texwipe.com](mailto:info@texwipe.com) for a copy.

Note: The data in this table represent typical analyses.

**For sterile products:**

- Gamma irradiated to a Sterility Assurance Level of 10<sup>-6</sup> according to AAMI Guidelines.
- Certificates of Compliance, Analysis and Irradiation attached to each case.
- Sterile Validation Documentation available upon request.

*Texwipe holds ISO 9001 and ISO 14001 registrations.*

*All Texwipe products conform to GHS classification for labeling (where applicable).*

*Shipping classification based on weight of inner package.*

# VersaWipe®

Dry | Sterile

TECHNICAL DATA SHEET



### Products

Number	Description	Sterile	Packaging	Case
<i>Dry Wipers – VersaWipe®</i>				
<b>TX624</b>	4" x 4" (10 cm x 10 cm) dry		1,200 wipers/bag (4 bags of 300 wipers)	10 bags
<b>STX624</b>	4" x 4" (10 cm x 10 cm) dry, sterile	●	50 wipers/bag	50 bags
<b>TX629</b>	9" x 9" (23 cm x 23 cm) dry		300 wipers/bag	10 bags
<b>TX622</b>	12" x 12" (31 cm x 31 cm) dry		150 wipers/bag	10 bags

TECHNICAL DATA SHEET

### Description

VersaWipe® is made from 45% polyester / 55% cellulose nonwoven material with a cut edge, cleanroom manufactured. Available dry (VersaWipe®) and sterile.

### Applications

- Wiping and cleaning surfaces, equipment and parts.
- Spill control.
- Applying and removing lubricants, adhesives, residues and other solutions including disinfectants.
- Cleaning with solvents such as isopropyl alcohol (IPA), ethanol, acetone, and degreasers.
- Lining trays for holding, protecting, drying and storing of parts, equipment and devices.
- Cleaning gloves, notebooks, phones or any other item entering the cleanroom.

### Industries

Aerospace	Animal Laboratory	Biologics
Cleanroom Design/Build	Compounding Pharmacies	Data Storage
Facilities Maintenance	Industrial	Laboratory
Medical Device	Microelectronics	Pharmaceutical
Printing/Graphics	Semiconductor	USP <797> / USP <800>

### Features & Benefits

- Constructed from a 45% polyester / 55% cellulose nonwoven creating a durable wiper ideal for spill control, cleaning, and solution application.
- Manufactured to provide low levels of particles and extractables creating a wiper suitable for general cleaning and wiping.
- Excellent chemical resistance for compatibility with a variety of solutions.
- Meets USP <797> and USP <800> wiper requirements.
- Autoclave safe.
- Individually lot coded for ease of traceability and quality control.

### Cleanroom Environment

- ISO Class 5 – 8
- Class 100 – 100,000
- EU Grade B – D

### Shelf Life

- Non-Sterile (Dry) – 5 years from date of manufacture
- Sterile (Dry) – 3 years from date of manufacture