## pure<sup>11</sup>



#### Anti-Fog Spray BioClean #BAFS-601

pure<sup>11</sup>-Nr.: 1120033, Marke: BioClean

#### Eigenschaften

Marke: BioClean

**Empfohlene Reinraumklassen** 

**ISO** 4|5|6|7|8|9

GMP A/B | C | D



#### Material

.

#### Verpackung

• 10STK

#### **Produktvarianten**

pure<sup>11</sup>-Nr.: 1120033, Anti-Fog Spray BioClean #BAFS-601

Steril; Gebinde: 60 ml / VE: 10STK

AG München HRB 171307

T +49 89 5589434 0

F +49 89 5589434 77

www.pure i i.ae

nfo@pure11.de



# BIOCLEAN ANTI-FOG SPRAY For Autoclavable Goggles BAFS

#### **About**

To address any fogging issues with our autoclavable goggles an application of BioClean Anti-fog Goggle Spray is recommended. The procedure for the successful application of the spray is as follows:

- 1. Autoclave the BioClean autoclavable goggles as usual
- 2. Just before donning, apply one or two sprays to the INSIDE of the lens
- 3. Using a sterile cleanroom wipe, dry the excess liquid from the inside surface of the lens with a spreading motion, covering the whole of the inside of the lens
- 4. Ensure the treated side of the lens is dry after wiping
- 5. Repeat the process after every autoclave cycle

#### **Specifications**

MATERIAL:

Non-hazardous ingredients

LENGTH:

60ml

COLOUR:

Colourless

STERILIZATION:

Gamma Irradiated

#### **Features**

- Reduces fogging
- · Airless pump action spray
- · Alcohol free
- · Quick and easy application
- Suitable for all BioClean autoclavable goggles







#### Quality Standards

 Manufactured in a facility holding ISO 9001:2015 and PPER 2016/425 Module D

#### Sterilization

Method: Gamma irradiation Minimum Dose: 25kGy

#### Shelf Life & Storage

Three (3) years from date of manufacture. Store in a dry, cool place (<40°C) away from direct sunlight and fluorescent light.

#### TO ORDER

Re-order code

BAFS-601 60ml

#### **Packing**

One bottle per sealed inner PE bag; one inner bag per second PE bag; 10 double bags per sealed outer PE bag; 10 outer bags per lined carton (100 bottles)

### For additional information visit us at www.bioclean.com, or call us at +44 1638 663338

Size

Nitritex Ltd Ground Floor, 15 Kings Court Willie Snaith Road Newmarket, Suffolk CB8 7SG United Kingdom

BAFS/1809/PDS12

**Ansell** 

Neither this document nor any other statement made herein by or on behalf of Ansell should be construed as a warranty of merchantability or that any Ansell product is fit for a particular purpose. Ansell assumes no responsibility for the suitability or adequacy of an end user's selection of accessory for a specific application.

Ansell, ® and TM are trademarks owned by Ansell Limited or one of its affiliates. © 2012 – 2019 Ansell Limited. All Rights Reserved.